



TurboTubs Spa/hot Tub Water Maintenance Schedule

TurboTubs Retail Store - 520 W. 5th Ave. Naperville (630)-305-9942

Using The Monarch + Ozone Chemical Reduction System

SPA MODEL: _____ GALLONS: _____

INITIAL START-UP / SPA DRAINING & REFILLING (DRAIN/REFILL EVERY 4 MONTHS)

* REPLACE DISPOSABLE MONARCH BLUE PURIFIER CARTRIDGE EVERY 4 MONTHS

ALWAYS REFILL SPA w/ FILL HOSE PLACED IN FILTER AREA (PURGES AIR OUT & AVOIDS PUMP AIRLOCK)

1. Water Test: Test Your Fill Water Ph & Alkalinity Level W/ Glb Test Strip

A. Dip Glb Spa Water Test Strip Inside Spa Under Water For 1 Second & Remove It:

B. Compare "Ph" Test Pad Color To Bottle Color Chart:

Yellow = Low Ph Acidic/corrosive Water

Orange = Neutral Ph/good Balanced Water

Red = High Ph /alkaline & Scale Forming Water

C. Compare "Alkalinity" Test Pad Color To Bottle Color Chart:

Yellow = Low Alkalinity Level/unstable Water (Big Ph Swings Up/down May Occur)

Green = Good Alkalinity Level/neutral Stable Water

Blue/green = High Alkalinity Level/over-stable Water (Resists Change Of The Ph Level)

* TURN ON SPA HIGH SPEED JET PUMPS TO MIX CHEMICALS INTO SPA WATER *

* ADD EACH CHEMICAL SLOWLY TO SPA , ONE AT A TIME, AT SPA FILTER AREA *

2. Adjust Alkalinity & Ph Levels If Needed:

* ADJUST ALKALINITY TO NORMAL LEVEL FIRST, BEFORE ADJUSTING PH (May Take 1-3 Weeks)

A. If Alkalinity Is Low - Add 1-2 Tablespoons Alkalinity Up

B. If Alkalinity Is High - Add 1-2 Teaspoons Or Tablespoons Ph Down (No Alkalinity Down)

C. If Ph Is Low - Add 2 Teaspoons / Tablespoons Ph Up

D. If Ph Is High - Add 2 Teaspoons / Tablespoons Ph Down

3. Add _____ Ounces Glb Natural Clear (Measure Using Blue Overcap- 1 Capful)

4. Add _____ Ounces Glb Activate (Measure Using Graph On Bottle Overcap)

5. Add _____ Tablespoons Glb Granular Spa Chlorine (Energizes System)

6. Add _____ Ounces Glb Protect Plus (Qt. Bottle Side Bar Graphs = 2 Oz. Each.)

7. Install Monarch Blue Purifier Stick (Place Under Water On Main Filter)

NOTE: MUST NOT INTERFERE W/ WATER FLOW (STRAINER BASKET) FROM SPA TO PUMP * CAN BE PUT INSIDE FILTER

* KEEP JETS ON HIGH 15-20 MINS. & SET HEATER TO DESIRED TEMPERATURE *

WEEKLY: SPA MAINTENANCE W/ OZONE & MONARCH CARTRIDGE PURIFIER

WEDNESDAY:

1. Clean Interior Waterline W/ Ultramitt (Removes Body Oils & Bather Residue)

2. Water Test: Dip Test Strip Below Water & Remove - Check Ph & Alkalinity Test

*NOTE: NEVER TEST FOR BROMINE / CHLORINE TEST LEVELS TURN ON SPA HIGH SPEED JET PUMPS WHEN ADDING CHEMICALS *

3. Adjust Alkalinity & Ph Levels If Needed Per Test Results

*(BALANCED WATER REDUCES FOAMING & SCALE BUILD-UP PROVIDING PURE AND CRYSTAL CLEAR SPA WATER)

4. Add 1-3 Teaspoons/tablespoons Glb Granular Spa Chlorine Only!

5. Add ___ Ounces Glb Protect Plus (Protects Equipment Against Mineral/scale Build-up)

FRIDAY:

1. Add Ounces Glb Activate (Eliminates Perspiration, Ammonia, Odors & Reactivates Dormant Chlorine Back Into Active "Free" Chlorine)

SUNDAY:

1. (Turn Power Off) Remove & Clean Filter (Rinse Out W/ Pressure Garden Hose Nozzle)

2. Add 1-3 Tsp/tablespoons Glb Granular Spa Chlorine (Only If Needed Based On Use)

* ADD WATER WEEKLY TO REFILL SPA TO NORMAL OPERATING LEVEL

MONTHLY:

1. Add Ounces Glb Spa Clarifier (Helps Filter Out Mascara/lotions For Clear Water)

2. Wipe Foam Spa Pillows W/ 303 Preservative Wipes Or Spray (Prolongs Pillow Life)

EVERY 4 MONTHS DRAIN & REFILL - (FOLLOW PAGE 1) & ADD TO ROUTINE:

1. (Power Off) Remove Filter(S) & Soak 12-24 Hrs. In Glb Filter Fresh Cleaner

2. (Power Off) Replace Disposable Monarch Blue Purifier Cartridge

EVERY 6 MONTHS: (SPRING & FALL)

1. Treat "Synthetic" Vinyl Spa Cabinet W/ "303" Brand Spray On Preserver

2. Clean & Condition Spa Cover - Clean W/ "Clean & Perfect" Cleaner

HAPPY HOT TUBBIN' FROM ENTIRE TURBO TUB'S STAFF - Call us with any questions!